



INSTALLATION INSTRUCTIONS

MAKE: Jeep
MODEL: Grand Cherokee (ZJ)
YEAR: 96-98
ENGINE: I6-4.0L

Cat Replacements
47-48006



EMISSIONS DISCLAIMER

This product is EPA compliant, not for sale or use on vehicles certified for the state of California. Consult your state or local authority for any additional clarification. Replacement of catalytic converters (if equipped) is allowed only under the following conditions: 1) It is missing or stolen; 2) It is damaged or lead poisoned as determined by a state or local inspection facility; or 3) It is outside of the manufacturer's warranty period (consult your owner's manual), if none stated, 5 years or 50,000 miles.

CAUTION: Allow time for your vehicle to cool down for atleast 2 hours prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

Step 1. (Read Instructions prior to installation.) Disconnect negative battery terminal.

Step 2. Remove O2 sensor. Check if damaged, replace if necessary.

Step 3. Unbolt clamps and remove catalytic converter from vehicle.

Step 4. Install aFe POWER catalytic converter.

Step 5. Connect O2 sensor to aFe POWER catalytic converter.

Step 6. Connect negative battery terminal.

Step 7. Double check your work, then proceed to start vehicle and check for any leaks.

Step 8. Your installation is now complete. It is recommended to re-tighten all exhaust components after 50-100 miles.