



Installation

Kit P/N:

TR-1004P (Polished)
TR-1004B (Wrinkle Black)

Make:

Honda

Model:

Civic Si (FG/FA) '06-'11

Engine:

L4-2.0L vtec

Parts Identification:

- 1 Air filter (**Pro Dry S™** TF-9003D)
- 1 Intake tube, 05-T1004P1 (Polished)
or 05-T1004B1 (Wrinkle Black)
- 1 Coupling, elbow 05-00135
- 2 Clamp #048
- 1 5/8" hose @ 8-1/2"L
- 1 5/16" hose @ 18"L
- 1 Nylon spacer
- 1 Flat washer M6
- 1 Nut M6
- 1 Wavy washer M6
- 2 Screw M4 x .7 x 8

Tools Required:

10mm socket or wrench
Ratchet w/ extension
Phillips screw driver
Flat head screw driver
5/16" nut driver
Pliers

Note: Perform install only when engine is cool. Read instructions before installation and have tools ready.

1



2



Complete Stock intake. *Please disconnect battery terminals before installation. Do not attempt to install kit if vehicle is not cold!*

3



With 10mm socket or wrench, loosen the 2 bolts securing the stock air box.

4



Disconnect MAF sensor harness.

5




Loosen the clamps on stock intake tube using 10mm socket. Remove the factory crank case line and vacuum line from the intake tube.

6



Remove complete stock air box out of vehicle including intake tube.

7



Remove crank case line attached with throttle body coolant line. Have a shop towel or rag handy to catch any leaking coolant. Use pliers to remove both lines. *Save small clamps for later install. Caution: Coolant may leak from line when removing!*

8



Replace throttle body coolant line with 5/16" hose provided and secure with clamps used from step 7.

9



Remove MAF sensor from stock air box using phillips screwdriver.



Accessories



Replacement Filter P/N:
TF-9003D



Pre Filter P/N:
TP-7011B

Note: Filter Cleaning: When cleaning your **Pro Dry S™** filter, be sure to use only "Restore Kit" (Takeda P/N: TP-7015C Pro Dry S™ cleaner only.)

Pro Dry S™ cleaning:
see cleaning instruction sheet TF-9000I.

For replacement part(s) or "Restore Kit" please log on to takedausa.com
P.O. Box 1719 Corona CA, 92878

10



Install MAF sensor to intake tube using new M4 screws provided.

11



Install air filter to intake tube and tighten using 5/16" nut driver.

12



Install elbow coupler to throttle body and position using clamps provided. Do not tighten.

13



With provided nylon spacer, place on air box mounting point.

14



Install intake into vehicle and position tab to mounting point and coupler.

15



Reinstall the crank case line using the 5/8" hose provided. Re-install vacuum line to new intake tube.

16



Tighten down intake using provided flat washer, wavy washer and M6 nut.

17



Tighten all clamps using 5/16" nut driver. Re-connect MAF sensor harness and battery terminals.

18



The installation of your Takeda performance intake is now complete. Please check all components and re-tighten if necessary. Thank you for choosing Takeda! Place the included CARB EO sticker on or near the intake system on a smooth, clean surface. E.O. identification label is required in passing the smog check inspection.