

advanced FLOW engineering Instruction Manual P/N: 51-10402-1 & 54-10402-1

Make: Hummer Model: H2 Year: 2003-2009 Engine: V8-6.0L & 6.2L





- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.

Retain factory parts for future use.

| Label | Qty. | Description | Part Number |
|-----------|------|------------------------------|-------------|
| <u>A1</u> | 1 | Air Filter (Pro 5R) | R24B91018 |
| <u>A2</u> | 1 | Air Filter (Pro DRY S) | R21B90020 |
| В | 1 | Tube | 05-00609 |
| <u>C</u> | 1 | Housing | 05-00147 |
| D | 5 | Washer, Wavy M6 | 03-50058 |
| <u>E</u> | 3 | Clamp 064 (2-1/2"-4 1/2") | 03-50006 |
| F | 1 | Clamp 072 (3"-5") | 03-50010 |
| G | 2 | Clamp, 060 (3-5/16"-4-1/4") | 03-50002 |
| <u>H</u> | 1 | Trim Seal 7/16" x 24" | 05-00072 |
| | 1 | Coupling, Straight | 05-00421 |
| J | 1 | Coupling, Reducer 4"x 3-3/4" | 05-00020 |
| K | 1 | Coupling, Reducer 4"x 3-1/2" | 05-00033 |
| L | 1 | Coupling 4 x 4 x 15° | 05-01226 |
| M | 5 | Screw, HD M6 x 1x 10 | 03-50113 |
| N | 1 | Hose, 3/8" x 13" | 05-00110 |
| 0 | 1 | Grommet, Rubber | 03-50268 |
| P | 1 | Fitting, Elbow 3/8" | 03-50151 |
| Q | 1 | Adaptor | 05-00611 |

Installation will require the following tools:


8mm nut driver, 6mm nut driver, 7mm nut driver, flat head screwdriver

Note: 2003-2005 vehicles are CARB exempt (D-550-3). 2006-2009 are currently not CARB exempt and is not available for sale or use in California. Please call Customer Service at 951-493-7100 for latest CARB status.



Page 3





Refer to Figure A for step 1-2

Step 1: Disconnect negative terminal from battery. Remove the 8mm engine cover bolt and set aside.

Step 2: Disconnect the MAF sensor (1).



Page 5

Refer to Figure B for steps 3-7

- Step 3: Loosen the hose clamp connecting the MAF sensor to the filter hosing (2).
- Step 4: Remove the three 10mm bolts securing the housing to the engine (3).
- Step 5: Loosen the clamps connecting the intake duct to the throttle body (4).
- Step 6: On 6.2L engines disconnect vent hose from engine (5).
- Step 7: Remove entire intake duct out of engine bay (6).





Refer to Figure C for step 8-9

- Step 8: Use a flathead screwdriver to remove the steel sleeve in the center.
- Step 9: Remove the three rubber mounts on the bottom of the airbox.



Refer to Figure D for step 10

Step 10: Transfer the rubber mounts to the new air filter housing. Use a bit of lubricant to ease installation of the mounts.






Refer to Figure E for steps 11-12

Step 11: Slide the filter adapter in to the housing.

Step 12: Bolt the adapter to the housing using the supplied M6 screws and washers.




Refer to Figure F for steps 13-14

Step 13: Place the rubber trim seal along edges of the housing.

Step 14: Bolt the housing to the engine bay using the factory bolts removed in step 4.





Refer to Figure G for step 15

Step 15: Install intake filter into housing.



Refer to Figure H for 6.2L Engine vent tube

Step 1: Dril a 5/8" hole at the tube part # location.

Step 2: Insert grommet 03-50268 into tube.

Step 3: Insert 3/8" elbow 03-50151 into grommet.

Step 4: Attach 3/8" hose onto elbow.

NOTE: THIS STEP APPLIES TO 6.2 ENGINES ONLY!





Refer to Figure I for steps 17-20

Step 17: Place straight coupler on throttle body and install intake tube. On 6.2L engines use 15° angle coupler (7).

Step 18: Tighten and secure all hose clamps. Attach vent hose to engine vent on 6.2L engines (8).

Step 19: Rotate fan to make sure there is sufficient clearance between the intake tube and the fan.

Step 20: Reconnect the MAF sensor harness (9).



Refer to Figure J for steps 22-23

- Step 22: Re-install the plastic engine cover. On 6.2L engines slight cover trimming is needed for clearance (10).
- Step 23: Your installation is now complete. Make sure you tighten all clamps and check all electrical connections. Re-check periodically.



Pro DRY S Air Filter



P/N: 21-90020

Pro 5R Air Filter



P/N: 24-91018

Blue Aerosol Restore Kit



P/N: 90-50001

Blue Squeeze Restore Kit



P/N: 90-50501

aFe Power Hat



P/N: 40-10083

To purchase any of the items above, view airflow charts, dyno graphs, photos, and video; please go to aFepower.com.

Warranty

General Terms:

- aFe warrants their products to be free from manufacturer's defects due to workmanship and material.
- This warranty applies only to the original purchaser of the product and is non-transferrable.
- Proof of purchase of the aFe product is required for all warranty claims.
- Warranty is valid provided aFe instructions for installation and/or cleaning were properly followed.
- Proper maintenance with regular inspections of product is required to insure warranty coverage.
- Damage due to improper installation, abuse, unauthorized repair or alteration is not warranted.
- Incidental or consequential damages or cost, including installation and removal of part, incurred due to failure of aFe
 product is not covered under this warranty.
- All warranty is limited to the repair and/or replacement of the aFe part. To request Return Goods Authorization ("RGA"), email RGA@afepower.com or call (951)493-7100. Upon receipt of the RGA, you must return the product to the address provided in the RGA, freight prepaid and accompanied with a dated proof of purchase and the RGA. Upon receipt of the defective product and upon verification of proof of purchase, aFe will either repair or replace the defective product within a reasonable time, not to exceed thirty days.

| Product Category | P/N Prefix | Warranty duration |
|----------------------------------|-----------------------------|---------------------|
| Direct OE Replacement Filters | 10, 11, 30, 31, 71, 73 | Life of the vehicle |
| Racing Filters | 18 | 1 year |
| Universal | 21, 24, 72,TF | 2 years |
| Air Intake Systems | 50, 51, 54, 55, 75,TR,TA,TL | 2 years |
| Exhaust Systems | 49 | 2 years |
| Intercoolers & Intercooler Tubes | 46-2 | 2 years |
| Intake Manifolds | 46-1 | 2 years |
| Differential Cover | 46-7 | Life of the vehicle |
| Exhaust Manifolds | 46 | 2 years |
| Throttle Body Spacers | 46-3 | 2 years |
| Turbochargers | 46-6 | 2 years* |
| Fluid Filters | 44 | 90 days |
| Pre-Filters | 28 | 2 years |
| Heavy Duty OE Replacement | 70 | 2 years |
| PowerSports OE Replacement | 81, 87 | 2 years |
| PowerSports Intake Systems | 85 | 2 years |

No other warranty expressed or implied applies nor is any person or advanced FLOW engineering authorized to assume any other warranty. Some States do not allow the exclusion or limitation of incidental or consequential damages or do not allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.

^{*}See turbocharger warranty for more info



advanced FLOW engineering, inc.

252 Granite Street Corona, CA 92879 TEL: 951.493.7100