

advanced FLOW engineering

**Instruction Manual** P/N: 77-43021

Make: **Ford** Model: **Mustang** Year: **2015-2020** Engine: **L4-2.3L (t) EcoBoost**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
A	1	Module	R77-43021
B	1	LED Switch	05-70029
C	2	Velcro (2 Inches)	05-01244
D	4	Cable Ties	05-60167

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.





# SLEEP MODE

Figure A

## **Refer to Figure A for Step 1.**

Step 1: Before installing your aFe module, you will have to place your vehicles ECU in sleep mode. In order to do this you will need to do the following:

- If the engine is cold, open the hood, close the doors lock the car and wait 30 seconds.
- If the engine is warm, open the hood, close the doors lock the car and wait 20 minutes.
- If the engine is warm and you can't wait 20 minutes, disconnect the battery.



**Note: Make sure connections are fully engaged. Usually, connectors make a snapping sound when fully engaged.**



Figure B

**Refer to Figure B for Step 2.**

Step 2: Locate the MAP and Turbocharger Boost Pressure (TCBP) sensors. The MAP sensor is located on the intake manifold on the right side of the engine. The TCBP is located on the bottom driver side of the intercooler, underneath the intercooler tube and headlights.



Figure C

### **Refer to Figure C for Steps 3-4.**

Step 3: Locate and disconnect the MAP sensor.

Step 4: Locate the MAP sensor jumper harness on the aFe module. This is the shorter harness with 4 wires on each connector. Plug the female connector of the module to the stock MAP sensor, then take the male connector of the module and connect to the female connector of the engine harness.

**Note:** Make sure connections are fully engaged. Usually, connectors make a snapping sound when fully engaged. There is a plastic insert on the stock male connector that may need to be removed before you can plug the connector into the female connector of the aFe harness.





Figure D

**Refer to Figures D for Steps 5-6.**

Step 5: Locate and disconnect the TCBP sensor. The sensor can be accessed from the top by sliding your hand down towards the bottom of the intercooler, or from the bottom by removing the under tray panel.

Step 6: Locate the TCBP sensor jumper harness on the aFe module. This is the longer harness with 3 wires on each connector. Plug the female connector of the module to the stock TCBP sensor, then the male connector of the module to the female connector of the engine harness.



**Note: There is a plastic insert on the stock male connector that may need to be removed before you can plug the connector into the female connector of the aFe harness.**



Figure E

**Refer to Figure E for Steps 7-8.**

Step 7: Carefully route the switch cable behind steering wheel cover.

Step 8: Mount the Switch on an open, flat surface.





Figure F

**Refer to Figure F for Step 9.**

Step 9: Route the switch cable through firewall and into the engine bay. Follow the main harness through the grommet into the firewall. Plug the end of the cable to the module.

**Figure G****Refer to Figure G for Step 10.**

Step 10: Mount the module in a safe location, using the supplied Velcro strip. Then, secure the wires and module away from any extreme heat and moving parts, with the provided ties.



**Note: Make sure connections are fully engaged. Usually, connectors make a snapping sound when fully engaged.**



Figure H

**Refer to Figure H for Step 11.**


Step 11: When turning on the vehicle, each LED will flash. It will stop at its last setting.

The LED on the switch represents the different level of power.

- Green LED: Stock
- Yellow LED: Sport
- Orange LED: Sport+
- Red LED: Race

Use the grey button to select the desired setting. Power adjustments can be done at any moment.

Thank you for choosing aFe POWER!



**advanced FLOW engineering, inc.**  
252 Granite Street Corona, CA 92879